


# Conventional Fire Detection System ACS-1-FD

## Description

ACS-1-FD is a pure Fire Detection and Alarm-System according to



- FSS-Code Chapter 9
- EN 54-2 (Control Panel)
- EN 54-4 (Energy Supply)
- IEC 60092 - 504

## Fire Alarm Panel CP-100 in Enclosure



CP-100 in Module Cabinet MC-308

Typ: CP-100 and MC-308

Art.No.: ACS01.100 and ACS.01.308

The Fire Alarm Panel displays fire alarms and faults states as well as the status of the extinguishing system. All alarms and faults will be shown on a large LCD display with clear text indication of the appropriate extinguishing section. Bright indicator lamps indicate FIRE / EXTINGUISHING / FAULT / TEST / DISABLED / POWER. An integrated dimmer automatically adapts the brightness of the indicator lamps and the backlight of the display according to the brightness of the environment. Can be configured as main fire alarm panel or remote alarm panel. For cable connection the adapter BG06.170 is required.

## Remote Display Panel CP-411



Remote Display Panel for ACS-1-FD

Typ: CP-411

Art. No. ACS01.411

The Remote Display Panel for Fire Detection Systems displays fire alarm of max. 14 fire detector loops. A green LED shows operation of the system (POWER). Two yellow LEDs indicate disabled loops (DISABLED) and system faults (FAULT). The function of each LED is described with exchangeable labels. The LEDs can also be configured for display of other signals. The brightness of the LEDs can be dimmed between 0 und 100%. System integration by 4-wire-CAN-Bus. Adapter BG06.170 is required.

## Downloads

[Downloads for ACS-1](#)